PPVS-INFUSION VACUUM SENSOR VALVE

MagnumVenusPlastech

Rev. 03/2013

CORPORATE HEADQUARTERS and MANUFACTURING
11692 56th Court * Clearwater, FL 33760 * Tel 727-573-2955 * Fax 727-571-3636

TECHNOLOGY CENTER and WEST COAST MANUFACTURING
1862 Ives Ave. * Kent, WA 98032 * Tel 253-854-2660 * Fax 253-854-1666

MVP PLASTECH UK
Chilsworthy Beam, Gunnislake, Cornwall, PL18 9AT UK, * Tel:+44 (0) 1822 832621
Fax: +44 (0) 1822 833999

www.mvpind.com

Table of Contents

SECTION:	Page
TERMS & CONDITIONS OF SALE	4
SAFETY & WARNINGS	7
INTRODUCTION	16
OVERVIEW	17
CONNECTIONS & POSITIONING	19
OPERATING PROCEDURES	22
ADJUSTING THE PPVS VALVE	24
MAINTENANCE	26
SPECIFICATIONS	27
PARTS DRAWINGS	28
REVISION INFORMATION	31

Terms & Conditions of Sale:

1. **ACCEPTANCE**: Acceptance of any purchase order from a customer or potential customer ("Buyer") is subject to credit approval by GSSC, Inc. ("Seller"), acceptance of the purchase order by Seller and, when applicable, any manufacturer, vendor, or other third party that provides goods to Seller for resale to Buyer ("Vendor"). If Seller, in its sole discretion, determines that Buyer's credit becomes unsatisfactory or it has reasonable grounds for insecurity, Seller reserves the right, upon notice to Buyer, to demand adequate assurance of due performance from Buyer and/or terminate any purchase order with no liability to Seller. BY REQUESTING A QUOTE FROM SELLER, ACCEPTING AN INVOICE FROM SELLER, OR PRESENTING A PURCHASE ORDER TO SELLER, BUYER CONFIRMS THAT THESE TERMS & CONDITIONS SHALL GOVERN ALL PURCHASES OF PRODUCTS OR MATERIALS PROVIDED TO BUYER BY SELLER ("GOODS"). GOODS SOLD BY SELLER ARE EXPRESSLY SUBJECT TO THE TERMS AND CONDITIONS SET FORTH HEREIN AND ANY DIFFERENT OR ADDITIONAL TERMS OR CONDITIONS SET FORTH IN A PURCHASE ORDER OR SIMILAR COMMUNICATION RECEIVED FROM BUYER ARE OBJECTED TO AND SHALL NOT BE BINDING UPON SELLER UNLESS SPECIFICALLY AGREED TO IN WRITING BY AN AUTHORIZED CORPORATE OFFICER OF SELLER.NO SELLER EMPLOYEE OR AGENT HAS THE AUTHORITY TO MODIFY THESE TERMS & CONDITIONS VERBALLY. SELLER OBJECTS TO AND REJECTS ANY TERMS BETWEEN BUYER AND ANY OTHER PARTY, AND NO SUCH TERMS, INCLUDING BUT NOT LIMITED TO ANY GOVERNMENT REGULATIONS OR "FLOWDOWN" TERMS, SHALL BE A PART OF OR INCORPORATED INTO ANY PURCHASE ORDER FROM BUYER TO SELLER, UNLESS AGREED TO IN WRITING BY AN AUTHORIZED REPRESENTATIVE OF SELLER.
2. **PRICES AND TAXES**: Buyer agrees to pay the prices quoted by Seller or listed on any related invoice, and is responsible for additional applicable shipping and handling charges, taxes, duties, and charges for import and export licenses and certificates. All prices quoted by Seller are subject to change without notice. Seller will generally collect applicable taxes along with the purchase price unless Buyer submits a valid tax exemption certificate, and indicates which Goods are covered by it. Prices on special-order Goods may be subject to change before shipment. In order to be corrected any discrepancies in pricing and/or quantities on invoices must be reported by Buyer within thirty (30) days of the invoice date.
3. **PAYMENT**: Payment terms are 30 days net from the invoice date or upon such other terms approved by Seller in writing. Retainage shall not apply, and Buyer shall not hold back any retainage from Seller, even if retainage is part of any contract between Buyer and any other party. Payment is not contingent on Buyer's ability to collect or obtain funds from any other party. Credit card sales are billed at the time of purchase. Buyer expressly represents it is solvent at the time it places any purchase order with Seller. Seller, in its sole discretion, may determine that Buyer's financial condition requires full or partial payment prior to manufacture or shipment. If Buyer fails to make any payment when due, Seller reserves the right to suspend performance. Buyer agrees to pay a charge on all amounts past due at the rate of 1 ½% per month (18% per year) or the maximum lawful rate, whichever is less. In the event of non-payment, Buyer agrees to pay Seller's reasonable attorney fees and court costs, if any, incurred by Seller to collect payment, and all applicable interest charges. **Seller may apply payments to any outstanding invoices unless Buyer provides specific payment direction.**
4. **TITLE AND RISK OF LOSS OR DAMAGE**: As to Goods delivered directly by Seller, title passes upon delivery at the place Buyer receives possession; and, thereafter, all risk of loss or damage shall be on Buyer. All other sales are F.O.B., point of shipment, and Buyer takes title and assumes responsibility for risk of loss or damage at the point of shipment for such sales. Claims for Goods damaged in transit are Buyer's sole responsibility when not delivered directly by Seller.
5. **QUOTATIONS**: All quotations expire thirty (30) days from the date of the quotation unless otherwise noted on the quotation. This time limit applies even if Buyer uses the quotation to submit a job or project bid to any other party.
6. **ASSIGNMENT**: The Buyer's rights and responsibilities under any purchase order or these Terms & Conditions shall not be assigned by Buyer without the express written consent of the Seller.
7. **RETURN OF GOODS:** Permission to return items must be requested and granted in advance. No credit will be given if items are returned prior to requesting and receiving permission. Subject to the foregoing, Seller shall accept returns of Goods for any reason for a period of thirty (30) days following shipment for exchange or refund of the purchase price; provided, that such Goods must be unused and are subject to a 15% restocking charge, which may be increased or decreased, in the Seller's sole discretion, depending on the reason for such return. Any Goods which were special ordered by Buyer are may not be returned, and any such Goods which are returned are subject to a restocking/cancellation fee of 100% of the cost of the Goods. Goods shall be deemed accepted by Buyer (and cannot thereafter be returned), if Buyer fails to object to the Goods within thirty (30) days after the Goods are received by Buyer.
8. **CANCELLATION:** The Buyer may cancel any purchase order prior to shipment of the Goods by mutual agreement of the parties and upon payment to Seller of reasonable and proper cancellation charges.
9. **TERMINATION:** Seller may terminate the whole or any part of any purchase order if there is a material breach of these Terms & Conditions. In the event of any such breach, the Seller will provide Buyer with written notice of the nature of the breach and the Seller's intention to terminate for default. In the event Buyer does not cure such failure within ten (10) days of such notice, Seller may, by written notice, terminate the purchase order; provided, that Buyer shall continue its performance to the extent not terminated.
10. **CHANGE IN BUYER'S FINANCIAL CONDITION:** Seller reserves the right to cancel any order or to require full or partial payment in advance without liability to Seller in the event of: (i) insolvency of the Buyer; (ii) the filing of voluntary petition in bankruptcy by Buyer; (iii) the appointment of a Receiver or Trustee for the Buyer; (iv) the execution by Buyer of an assignment for benefit of creditors; or (v) past due payment on previous shipments to Buyer by Seller. Seller reserves the right to cancel Buyers credit at any time for any reason.
11. **INTERPRETATION RESPONSIBILITY; PRODUCT USE AND SAFETY**: Seller does not guarantee that the Goods it sells conform to any plans and specifications or intended use. When plans and specifications are involved, Buyer is solely responsible for verifying Seller's interpretations of such plans and specifications, and it is Buyer's sole responsibility to assure that Seller's Goods will be acceptable for any specific job. When Seller offers substitute Goods on any proposal, Buyer is solely responsible for confirming their acceptability.
12. **DELIVERY**: Shipping dates given in advance of actual shipment are approximate and not guaranteed. All contract dates and timelines begin upon receipt by Seller of a purchase order, Buyer's acceptance of these Terms & Conditions, and the payment of any required down payment.

13. **EXCUSABLE DELAYS**: Seller shall have no liability if its performance is delayed or prevented by causes beyond its reasonable control, including, without limitation, acts of nature, labor disputes, government priorities, transportation delays, insolvency or other inability to perform by any Vendor, or any other commercial impracticability. In the event of any such delay, the date of delivery or performance shall be extended for a period equal to the time lost by reason of delay. If Goods are held or stored beyond the delivery date for the convenience of Buyer, such Goods shall be so stored at the risk and expense of Buyer.

14. **CLAIMS:** Claims for any nonconforming Goods must be made by Buyer, in writing, within ten (10) days of Buyer's receipt of such Goods and must state with particularity all material facts concerning the claim then known to Buyer. Failure by Buyer to give notice within such ten (10) day period shall constitute an unqualified acceptance of such Goods by Buyer, and a waiver of any right to reject or revoke acceptance of such Goods.

15. **WARRANTIES**:

(a) SELLER'S WARRANTIES: Seller warrants that all Goods sold shall mechanically operate as specified and shall be free from faults in respect to materials and workmanship for a period of: (i) for parts, twelve (12) months from the date of invoice, and (ii) for systems, twelve (12) months from start-up, or, if earlier, eighteen (18) months from the date of the bill of lading. Seller also warrants that the Goods shall, upon payment in full by Buyer for the Goods, be free and clear of any security interests or liens. Buyer's exclusive remedy for breach of such warranties shall be limited to repair or replacement costs or termination of any security interests or liens, and Seller shall have no responsibility for reimbursing repair costs incurred by Byer in connection with Goods without first giving written authorization for such charges. In any claims by the Buyer against the Seller in respect of the Goods, the liability of the Seller shall be limited to the value of the Goods. This warranty applies only to Goods properly used and maintained and does not apply to any Goods which are misused, neglect or accident, or which has been installed, operated, repaired, altered or modified other than in accordance with instructions or written authorization by Seller. This warranty does not apply to any Goods not manufactured by Seller, and Buyer's sole warranty with respect to such Goods shall be that of the Seller's Vendor, if any.

(b) VENDOR'S WARRANTIES: Seller shall assign to Buyer any Vendor warranties and/or remedies provided to Seller by its Vendor.

(c) INTELLECTUAL PROPERTY INFRINGEMENT: SELLER DISCLAIMS ANY AND ALL WARRANTIES AND/OR INDEMNIFICATIONS AGAINST INFRINGEMENT OF ANY INTELLECTUAL PROPERTY RIGHTS OF ANY NATURE. SELLER SHALL, IF GIVEN PROMPT NOTICE BY BUYER OF ANY CLAIM OF INTELLECTUAL PROPERTY INFRINGEMENT WITH RESPECT TO ANY GOODS SOLD HEREUNDER, REQUEST THE APPLICABLE VENDOR TO GRANT FOR THE BUYER SUCH WARRANTY OR INDEMNITY RIGHTS AS SUCH VENDOR MAY CUSTOMARILY GIVE WITH RESPECT TO SUCH GOODS.

(d) LIMITATIONS: THERE ARE NO OTHER WARRANTIES WRITTEN OR ORAL, EXPRESS, IMPLIED OR BY STATUTE. SELLER SPECIFICALLY DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. NO REPAIR OF GOODS OR OTHER COSTS ARE ASSUMED BY SELLER UNLESS AGREED TO, IN ADVANCE, IN WRITING.

16. **LIMITATIONS OF LIABILITY**: UNLESS APPLICABLE LAW OTHERWISE REQUIRES, SELLER'S AND ANY VENDOR'S TOTAL LIABILITY TO BUYER, BUYER'S CUSTOMERS OR TO ANY OTHER PERSON, RELATING TO ANY PURCHASES GOVERNED BY THESE TERMS & CONDITIONS, FROM THE USE OF THE GOODS FURNISHED OR FROM ANY ADVICE, INFORMATION OR ASSISTANCE PROVIDED BY SELLER (BY ANY METHOD, INCLUDING A WEB SITE), IS LIMITED TO THE PRICE OF THE GOODS GIVING RISE TO THE CLAIM. NEITHER SELLER NOR ITS VENDORS SHALL BE LIABLE FOR ANY SPECIAL, INCIDENTAL, DIRECT, CONSEQUENTIAL OR PENAL DAMAGES, INCLUDING, BUT NOT LIMITED TO BACKCHARGES, LABOR COSTS, COSTS OF REMOVAL, REPLACEMENT, TESTING OR INSTALLATION, LOSS OF EFFICIENCY, LOSS OF PROFITS OR REVENUES, LOSS OF USE OF THE GOODS OR ANY ASSOCIATED GOODS, DAMAGE TO ASSOCIATED GOODS, LATENESS OR DELAYS IN DELIVERY, UNAVAILABILITY OF GOODS, COST OF CAPITAL, COST OF SUBSTITUTE GOODS, FACILITIES OR SERVICES, DOWNTIME, OR CLAIMS FROM BUYER'S CUSTOMERS OR OTHER PARTIES. IF SELLER FURNISHES BUYER WITH ADVICE OR OTHER ASSISTANCE WHICH CONCERNS ANY GOODS SUPPLIED HEREUNDER, OR ANY SYSTEM OR EQUIPMENT IN WHICH ANY SUCH GOODS MAY BE INSTALLED, AND WHICH IS NOT REQUIRED PURSUANT TO THESE TERMS & CONDITIONS, THE FURNISHING OF SUCH ADVICE OR ASSISTANCE WILL NOT SUBJECT SELLER TO ANY LIABILITY, WHETHER BASED ON CONTRACT, WARRANTY, TORT (INCLUDING NEGLIGENCE) OR OTHER GROUNDS.

17. **BUYER'S USE OF GOODS**: Many factors beyond Seller's control contribute to the success of the Buyer's finished products, such as raw materials used to manufacture the products. Seller is not liability for the quality or quantity of finished products produced by Buyer with the use of the Goods.

18. **EXPORTS:** If Goods are sold for export, Seller's standard terms & condition for export sales, if any, shall also apply. Acceptance of export orders is not valid unless confirmed in writing by Seller. Buyer, and not Seller, is responsible for compliance with all United States export control rules and regulations. Buyer shall not name Seller as shipper or exporter of record in connection with the export of any Goods purchased from Seller.

19. **INSTALLATION**: Installation of the Goods is the responsibility of Buyer, unless otherwise indicated in the quotation or invoice provided to Buyer. Notwithstanding the foregoing, however, Seller will provide installation supervision personnel within thirty (30) days of Buyer's request. If an installation for which the Seller is to participate is delayed by the Buyer more than six (6) months after the date of shipment of the Goods, or if Buyer's facility, materials, or parts are not prepared for installation for such period of time, Seller shall be entitled to invoice the Buyer for the anticipated installation costs, up to $1,250 per day plus expenses, for each of Seller's installations technicians which are on site.

20. **ANTI-MONEY LAUNDERING RESTRICTIONS**: Seller rejects questionable purchase orders and payments: Except for pre-approved credit arrangements, Seller rejects third-party payments, cashiers' checks, money orders and bank drafts. Seller accepts only checks imprinted with Buyer's name; wire transfers originated in Buyer's account; letters of credit with Buyer as account party; and credit or debit cards in Buyer's name. All payments must be by single instrument in the amount of the invoice, less credits, from banks acceptable to Seller.

21. **GOVERNING LAW**: These Terms & Conditions and all disputes related to it shall be governed by the laws of the State of Florida, United States of America, without giving effect to its conflict of law rules.

22. **JURISDICTION AND VENUE:** The parties hereby irrevocably submit to the jurisdiction of the state courts of the State of Florida and to the jurisdiction of the United States District Court for the Middle District of Florida, for the purpose of any suit, action, or other proceeding related to, arising out of or based upon these Terms & Conditions or in any way related to, arising out of or involving sale of Goods hereunder; waive and agree not to assert by way of motion, as a defense, or otherwise, in any such suit, action, or proceeding, any claim that it is not subject personally to the jurisdiction of the above-named courts, that its property is exempt or immune from attachment or execution, that the suit, action, or proceeding is brought in any inconvenient forum, that the venue of the suit, action, or proceeding is improper, or that these Terms & Conditions or the subject matter hereof may not be enforced in or by such court; and waive and agree not to seek any review by any court of any other jurisdiction which may be called upon to grant an enforcement of the judgment of any such Florida state or federal court. The parties hereby consent to service of process by registered mail at the address to which notice is to be given. The exclusive venue for any proceeding under these Terms & Conditions shall be solely in any state court in Pinellas County, Florida, or the Federal District Court for the Middle District of Florida, Tampa Division, sitting in Tampa, Florida. Buyer acknowledges that the prices for Goods offered hereunder are in part dependent on Buyer's consent to jurisdiction in Florida and exclusive venue in Pinellas County, Florida or the Federal District Court for the Middle District of Florida, Tampa Division, sitting in Tampa, Florida, and without Buyer's consent to this jurisdiction and venue provision the prices for the Goods may be higher.

23. **GENERAL:** Any representation, affirmation of fact and course of dealing, promise or condition in connection therewith or usage of trade not contained herein, shall not be binding on either party. If any provision hereof shall be unenforceable, invalid or void for any reason, such provision shall be automatically voided and shall not be part of these Terms & Conditions and the enforceability or validity of the remaining provisions of these Terms & Conditions shall not be affected thereby.

TO THE EXTENT NOT CONTRARY TO APPLICABLE LAW, THE FOLLOWING SHALL APPLY:

24. Buyer waives any available homestead exemption as well as any and all requirements or rights with regard to notice, demand, presentment, or protest and appoint any employee or attorney of Seller to appear in any court of competent jurisdiction for the purpose of confessing judgment for all amounts due Seller pursuant to these terms and conditions.

25. Buyer hereby waives all rights to notice, judicial hearing or prior court order in connection with Seller's obtaining any prejudgment remedy in connection with said transactions or extensions of same. Buyer also waives any and all objection which Buyer might otherwise be able to assert now or in the future to the exercise or use by Seller of any right of setoff, repossession or self-help as may presently exist under statute, including the Uniform Commercial Code and common law.

IMPORTANT NOTICE: *THIS INSTRUMENT PERMITS SELLER TO OBTAIN AND USE YOUR INDIVIDUAL CREDIT HISTORY FOR CREDIT EVALUATION PURPOSES. THIS INSTRUMENT FURTHER CONTAINS A CONFESSION OF JUDGMENT PROVISION AND OTHER WAIVERS, WHICH CONSTITUTES A WAIVER OF IMPORTANT RIGHTS YOU MAY HAVE, AND IF YOU DO NOT PAY ON TIME, ALLOWS SELLER TO OBTAIN A JUDGMENT AGAINST YOU WITHOUT FURTHER NOTICE OR YOUR PRIOR KNOWLEDGE. BY ACCEPTING THESE TERMS YOU GIVE UP YOUR RIGHT TO NOTICE AND TRIAL. THE POWERS OF THE COURT CAN BE USED TO COLLECT THE AMOUNT DUE REGARDLESS OF ANY CLAIMS YOU MAY HAVE WHETHER FOR RETURNED OR FAULTY GOODS, FAILURE BY SELLER TO COMPLY WITH THESE TERMS & CONDITIONS, OR ANY OTHER CAUSE.*

SAFETY & WARNING INFORMATION:

OPERATING YOUR POLYESTER SYSTEM SAFELY

1. Introduction

Any tool, if used improperly, can be dangerous. Safety is ultimately the responsibility of those using the tool. In like manner, safe operation of polyester processes is the responsibility of those who use such processes and those who operate the equipment. This manual outlines procedures to be followed in conducting polyester operations safety. This system has been specifically designed for use of Polyester Resin, Gel-Coat, and Methyl Ethyl Ketone Peroxides (MEKP) applications. Other formulations or blends considered for use in this equipment is strictly prohibited without the expressed consent by Magnum Venus Plastech Inc. Magnum Venus Plastech cannot eliminate every danger nor foresee every circumstance that might cause an injury during equipment operation. Some risks, such as the high pressure liquid stream that exits the spray tip, are inherent to the nature of the machine operation and are necessary to the process in order to manufacture the end-product. For this reason, ALL personnel involved in polyester operations should read and understand the Safety Manual. It is very important for the safety of employees involved in the operation that equipment operators, maintenance and supervisory personnel understand the requirements for safe operation. Each user should examine his own operation, develop his own safety program and be assured that his equipment operators follow correct procedures. Magnum Venus Plastech hopes that this manual is helpful to the user and recommends that the precautions in this manual be included in any such program. Magnum Venus Plastech recommends this Safety Manual remain on your equipment at all times for your personnel safety. In addition to the manual, Magnum Venus Plastech recommends that the user consult the regulations established under the Occupational Safety & Health Act (OSHA), particularly the following sections:

1910.94 Pertaining to Ventilation.

1910.106 Pertaining to flammable liquids

1910.107 Pertaining to spray finishing operations, particularly Paragraph (m) Organic Peroxides and Dual Component Coatings.

Other standards and recognized authorities to consult are the National Fire Protection Association (NFPA) bulletins as follows:

NFPA No.33 Chapter 14, Organic Peroxides and Dual Component Materials

NFPA No.63 Dust Explosion Prevention

NFPA No.70 National Electrical Code

NFPA No.77 Static Electricity

NFPA No.91 Blower and Exhaust System

NFPA No.654 Plastics Industry Dust Hazards

Type of Fire Extinguishing equipment recommended: Fire Extinguisher – code ABC, rating number 4a60bc.

Extinguishing Media – Foam, Carbon Dioxide, Dry Chemical, Water Fog.

Copies of the above bulletins are available, at a nominal charge from:

National Fire Protection Association
470 Atlantic Avenue
Boston, MA 02210

Research Report No.11 of the American Insurance Association deal with “Fire, Explosion and Health Hazards of Organic Peroxides”. It is published by:

American Insurance Association
85 John Street
New York, NY 10038

Local codes and authorities also have standards to be followed in the operation of your spraying equipment. Your insurance carrier will be helpful in answering questions that arise in your development of safe procedures.

1.2 Personal Safety Equipment

Magnum Venus Plastech recommends the following Personal Safety Equipment for conducting safe operations of the Polyester Systems:

Magnum Venus Plastech recommends that the user consult the state and local regulations established for all Safety equipment listed.

2.0 Material Safety

2.1 Hazards Associated with Laminating Operations

The major hazards which should be guarded against in polyester laminating operations are those associated with:

1. The flammability and explosion dangers of the catalyst normally used – Methyl Ethyl Ketone Peroxide (MEKP).

2. The flammability dangers of clean-up solvents sometimes used (Magnum Venus Plastech recommends that clean-up solvents be non-flammable), and of resin diluents used, such as styrene.

3. The flammability dangers of catalyst diluents, if used. (Magnum Venus Plastech recommends that catalyst not be diluted.

4. The flammability dangers of the uncured liquid resins used.

5. The combustibility dangers of the cured laminate, accumulations of over spray, and laminate sandings.

6. The toxicity dangers of all the chemicals used in laminating operations with respect to ingestion, inhalation and skin and eye hazards.

2.2 Catalyst (Methyl Ethyl Ketone Peroxide)

MEKP is among the more hazardous materials found in commercial channels. The safe handling of the "unstable (reactive)" chemicals presents a definite challenge to the plastics industry. The highly reactive property which makes MEKP valuable to the plastics industry in producing the curing reaction of polyester resins also produces the hazards which require great care and caution in its storage, transportation, handling, processing and disposal. MEKP is a single chemical. Various polymeric forms may exist which are more or less hazardous with respect to each other. These differences may arise not only from different molecular structures (all are, nevertheless, called "MEKP") and from possible trace impurities left from the manufacture of the chemicals, but may also arise by contamination of MEKP with other materials in its storage or use. Even a small amount of contamination with acetone, for instance, may produce an extremely shock-sensitive and explosive compound.

Contamination with promoters or materials containing promoters, such as laminate sandings, or with any readily oxidizing material, such as brass or iron, will cause exothermic "redox" reactions which can become explosive in nature. Heat applied to MEKP, or heat build-up from contamination reactions can cause it to reach what is called its Self-Accelerating Decomposition Temperature (SADT).

Researchers have reported measuring pressure rates-of-rise well in excess of 100,000 psi per second when certain MEKP's reach their SADT. (For comparison, the highest pressure rate-of-rise listed in NFPA Bulletin NO.68, "Explosion Venting", is 12,000 psi per second for an explosion of 12% acetylene and air. The maximum value listed for a hydrogen explosion is 10,000 psi per second. Some forms of MEKP, if allowed to reach their SADT, will burst even an open topped container. This suggests that it is not possible to design a relief valve to vent this order of magnitude of pressure rate-of-rise. The user should be aware that any closed container, be it a pressure vessel, surge chamber, or pressure accumulator, could explode under certain conditions. There is no engineering substitute for care by the user in handling organic peroxide catalysts. If, at any time, the pressure relieve valve on top of the catalyst tank should vent, the area should be evacuated at once and the fire department called. The venting could be the first indication of a heat, and therefore, pressure build-up that could eventually lead to an explosion. Moreover, if a catalyst tank is sufficiently full when the pressure relief valve vents, some catalyst may spray out, which could cause eye injury. For this reason, and many others, anyone whose job puts them in an area where this vented spray might go, should always wear full eye protection even when laminating operations are not taking place.

Safety in handling MEKP depends to a great extent on employee education, proper safety instructions and safe use of the chemicals and equipment. Workers should be thoroughly informed of the hazards that may result from improper handling of MEKP, especially in regards to contamination, heat, friction and impact. They should be thoroughly instructed regarding the proper action to be taken in the storage, use and disposal of MEKP and other hazardous materials used in the laminating operation. In addition, users should make every effort to:

A. Store MEKP in a cool, dry place in original containers away from direct sunlight and away from other chemicals.

B. Keep MEKP away from heat, sparks and open flames.

C. Prevent contamination of MEKP with other materials, including polyester over spray and sandings, polymerization accelerators and promoters, brass, aluminum and non-stainless steels.

D. Never add MEKP to anything that is hot, since explosive decomposition may result.

E. Avoid contact with skin, eyes and clothing. Protective equipment should be worn at all times. During clean-up of spilled MEKP, personal safety equipment, gloves and eye protection must be worn. Fire fighting equipment should be at hand and ready.

F. Avoid spillage, which can heat up to the point of self-ignition.

G. Repair any leaks discovered in the catalyst system immediately, and clean up the leaked catalyst at once in accordance with the catalyst manufacturer's instructions.

H. Use only original equipment or equivalent parts from Magnum Venus Plastech in the catalyst system (i.e.: hoses, fitting, etc.) because a dangerous chemical reaction may result between substituted parts and MEKP.

I. Catalyst accumulated from the purging of hoses or the measurement of fluid output deliveries should never be returned to the supply tank, such catalyst should be diluted with copious quantities of clean water and disposed of in accordance with the catalyst manufacturer's instructions.

The extent to which the user is successful in accomplishing these ends and any additional recommendations by the catalyst manufacturer determines largely the safety that will be present in his operation.

2.3 Clean-Up Solvents and Resin Diluents

WARNING

A hazardous situation may be present in your pressurized fluid system! Hydrocarbon Solvents can cause an explosion when used with aluminum or galvanized components in a closed (pressurized) fluid system (pump, heaters, filters, valves, spray guns, tanks, etc.). The explosion could cause serious injury, death and/or substantial property damage. Cleaning agents, coatings, paints, etc. may contain Halogenated Hydrocarbon Solvents. Some Magnum Venus Plastech spray equipment includes aluminum or galvanized components and will be affected by Halogenated Hydrocarbon Solvents.

A. There are three key elements to the Halogenated Hydrocarbon (HHC) solvent hazard.

a. The presence of HHC solvents. 1,1,1 – Trichloroethane and Methylene Chloride are the most common of these solvents. However, other HHC solvents are suspect if used; either as part of paint or adhesives formulation, or for clean-up flushing. b. Aluminum or Galvanized Parts. Most handling equipment contains these elements. In contact with these metals, HHC solvents could generate a corrosive reaction of a catalytic nature.

b. Equipment capable of withstanding pressure. When HHC solvent contact aluminum or galvanized parts inside a closed container such as a pump, spray gun, or fluid handling system, the chemical reaction can, over time, result in a build-up of heat and pressure, which can reach explosive proportions.

When all three elements are present, the result can be an extremely violent explosion. The reaction can be sustained with very little aluminum or galvanized metal; any amount of aluminum is too much.

A. The reaction is unpredictable. Prior use of an HHC solvent without incident (corrosion or explosion) does NOT mean that such use is safe. These solvents can be dangerous alone (as a clean-up or flushing agent) or when used as a component or a coating material. There is no known inhibitor that is effective under all circumstances. Furthermore, the mixing of HHC solvents with other materials or solvents, such as MEKP, alcohol, and toluene, may render the inhibitors ineffective.

B. The use of reclaimed solvents is particularly hazardous. Reclaimers may not add any inhibitors. Also, the possible presence of water in reclaimed solvents could feed the reaction.

C. Anodized or other oxide coatings cannot be relied upon to prevent the explosive reaction. Such coatings can be worn, cracked, scratched, or too thin to prevent contact. There is no known way to make oxide coatings or to employ aluminum alloys, which will safely prevent the chemical reaction under all circumstances.

D. Several solvent suppliers have recently begun promoting HHC solvents for use in coating systems. The increasing use of HHC solvents is increasing the risk. Because of their exemption from many State Implementation Plans as Volatile Organic Compounds

(VOC's), their low flammability hazard, and their not being classified as toxic or carcinogenic substances, HHC solvents are very desirable in many respects.

WARNING: **Do not use Halogenated Hydrocarbon solvents in pressurized fluid systems having aluminum or galvanized wetted parts.**

NOTE: **Magnum Venus Plastech is aware of NO stabilizers available to prevent Halogenated Hydrocarbon solvents from reaction under all conditions with aluminum components in closed fluid system.** ***TAKE IMMEDIATE ACTION…*** **Halogenated Hydrocarbon solvents are dangerous when used with aluminum components in a closed fluid system.**

A. Consult your material supplier to determine whether your solvent or coating contains Halogenated Hydrocarbon Solvents.

B. Magnum Venus Plastech recommends that you contact your solvent supplier regarding the best non-flammable clean-up solvent with the heat toxicity for your application.

C. If, however, you find it necessary to use flammable solvents, they must be kept in approved, electrically grounded containers.

D. Bulk solvent should be stored in a well-ventilated, separate building, 50 feet away from your main plant.

E. You should allow only enough solvent for one day's use in your laminating area.

F. "NO SMOKING" signs must be posted and observed in all areas of storage or where solvents and other flammable materials are used.

G. Adequate ventilation (as covered in OSHA Section 1910.94 and NFPA No.91) is important wherever solvents are stored or used, to minimize, confine and exhaust the solvent vapors.

H. Solvents should be handled in accordance with OSHA Section 1910.106 and 1910.107.

2.4 Catalyst Diluents

Magnum Venus Plastech spray-up and gel-coat systems currently produced are designed so that catalyst diluents are not required. Magnum Venus Plastech, therefore, recommends that diluents not be used. This avoids the possible contamination which could lead to an explosion due to the handling and mixing of MEKP and diluents. In addition, it eliminates any problems from the diluent being contaminated through rust particles in drums, poor quality control on the part of the diluents suppliers, or any other reason. If, however, diluents are absolutely required, contact your catalyst supplier and follow his instructions explicitly. Preferable, the supplier should premix the catalyst to prevent possible “on the job” contamination while mixing.

WARNING

If diluents are not used, it should be remembered that catalyst spillage, gun, hose and packing leaks are potentially more hazardous, since each drop contains a higher concentration of catalyst, and therefore will react quicker with over spray and the leak.

2.5 Cured Laminate, Overspray and Laminate Sandings Accumulation

A. Remove all accumulations of overspray, FRP sandings, etc. from the building as they occur. If this waste is allowed to build up, spillage of catalyst is more likely to start a fire; in addition, the fire would burn hotter and longer.

B. Floor coverings, if used, should be non-combustible.

C. Spilled or leaked catalyst may cause a fire if it comes in contact with an FRP product, over-sprayed chop or resin, FRP sandings or any other material with MEKP.

To prevent this spillage and leakage, you should:

1. Maintain your Magnum Venus Plastech System. Check the gun several times daily for catalyst and resin packing or valve leaks. REPAIR ALL LEAKS IMMEDIATELY.

2. Never leave the gun hanging over, or lying inside the mold. A catalyst leak in this situation would certainly damage the part, possibly the mold, and may cause a fire.

3. Inspect resin and catalyst hoses daily for wear or stress at the entry and exits of the boom sections and at the hose and fittings. Replace if wear or weakness is evident or suspected.

4. Arrange the hoses and fiberglass roving guides so that the fiberglass strands DO NOT rub against any of the hoses at any point. If allowed to rub, the hose will be cut through, causing a hazardous leakage of material which could increase the danger of fire. Also, the material may spew onto personnel in the area.

2.7 Toxicity of Chemicals

A. Magnum Venus Plastech recommends that you consult OSHA Sections 1910.94, 1910.106, 1910.107 and NFPA No.33, Chapter 14, and NFPA No.91.

B. Contact your chemical supplier(s) and determine the toxicity of the various chemicals used as well as the best methods to prevent injury, irritation and danger to personnel.

C. Also determine the best methods of first aid treatment for each chemical used in your plant.

2.8 Treatment of Chemical Injuries

Great care should be used in handling the chemicals (resins, catalyst and solvents) used in polyester systems. Such chemicals should be treated as if they hurt your skin and eyes and as if they are poison to your body. For this reason, Magnum Venus Plastech recommends the use of protective clothing and eye wear in using polyester systems. However, users should be prepared in the event of such an injury. Precautions include:

1. Know precisely what chemicals you are using and obtain information from your chemical supplier on what to do in the event the chemical gets onto your skin or into the eyes, or is swallowed.

2. Keep this information together and easily available so that it may be used by those administering first aid or treating the injured person.

3. Be sure the information from your chemical supplier includes instructions on how to treat any toxic effects the chemicals have.

WARNING

Contact your doctor immediately in the event of any injury and give him the information you have collected. If your information includes first aid instructions, administer first aid immediately while you are contacting your doctor.

Fast treatment of the outer skin and eyes that contact such chemicals generally includes immediate and thorough washing of the exposed skin and immediate and continuous flushing of the eyes with lots of clean water for at least 15 minutes or more. These general instructions of first aid treatment, however, may be incorrect for some chemicals; that is why you must know the chemicals and treatment before an accident occurs. Treatment for swallowing a chemical frequently depends upon the nature of the chemical.

NOTE: **Refer to your System User Manual for complete and detailed operating instructions and service information.**

3.0 Equipment Safety

WARNING

Magnum Venus Plastech suggests that personal safety equipment such as EYE GOGGLES, GLOVES, EAR PROTECTION, and RESPIRATORS be worn when servicing or operating this equipment. Ear protection should be worn when operating a fiberglass chopper to protect against hearing loss since noise levels can be as high as 116 dB (decibels). This equipment should only be operated or serviced by technically trained personnel!

WARNING

Never place fingers, hands, or any body part near or directly in front of the spray gun fluid tip. The force of the liquid as it exits the spray tip can cause serious injury by shooting liquid through the skin. NEVER LOOK DIRECTLY INTO THE GUN SPRAY TIP OR POINT THE GUN AT OR NEAR ANOTHER PERSON. (TREAT THE GUN AS IF IT WERE A LOADED PISTOL.)

3.1 Emergency Stop Procedures

The following steps should be followed in order to stop the machinery in an emergency situation

1. The ball valve located where the air enters the Powerhead of the resin pump, should be moved to the “OFF” or closed position. To do this, simply rotate the lever on the ball valve 90 degrees. Doing this will cause all the system air to bleed out of the system in a matter of a few seconds, making the system incapable of operating

NOTE: Step 2 is a precautionary step and should be followed whenever the above mentioned ball valve is activated to the stop mode. Failure to do so, can damage the regulators and components on reactivating to the “ON” position.

2. Turn all system regulators to the “OFF” position (counter-clockwise) position

NOTE: Verify that the Catalyst relief line, located on the catalyst manifold, and the resin return line, located on the resin filter, are secured relieving catalyst and resin fluid pressure.

3. Catalyst pressure in the catalyst pump can be eliminated by rotating the ball valve on the catalyst manifold 90 degrees to the “open” or “on” position.

Note: The “open” or “on” position is when the ball valve handle is parallel (in line) with the ball valve body. The “closed” or “off” position is when the ball valve handle is perpendicular (across) the ball valve body.

4. Resin pressure in the resin pump can be eliminated by rotating the ball valve on the resin filter 90 degrees to the “open” or “on” position. Place a container under the ball valve to catch any resin that is ejected out of the valve.

3.2 Grounding

Grounding an object means providing an adequate path for the flow of the electrical charge from the object to the ground. An adequate path is one that permits a charge to flow from the object fast enough that it will not accumulate to the extent that a spark can be formed. It is not possible to define exactly what will be an adequate path under all conditions since it depends on many variables. In any event, the grounding means should have the lowest possible electrical resistance. Grounding straps should be installed on all loose conductive objects in the spraying area. This includes material containers and equipment. Magnum Venus Plastech recommends grounding straps be made of AWG No.18 stranded wire as a minimum and the larger wire be used where possible. NFPA Bulletin No77 states that the electrical resistance of such a leakage path may be as low as 1 meg ohm (10 ohms) but that resistance as high as 10,000 meg ohms will produce an adequate leakage path in some cases. Whenever flammable or combustible liquids are transferred from one container to another, or from one container to the equipment, both containers or container and equipment shall be effectively bonded and grounded to dissipate static electricity. For further information, see **National Fire Protection Association** (NFPA) 77, titled "Recommended Practice on Static Electrical". Refer especially to section 7-7 titled "Spray Application of Flammable and Combustible Materials". Check with local codes and authorities for other specific standards that might apply to your application. NEVER USE HARD MATERIALS SUCH AS WIRE, PINS, ETC., TO CLEAR A PLUGGED GUN. HARD MATERIALS CAN CAUSE PERMANENT DAMAGE. DAB WITH A BRISTLE BRUSH, BLOW BACKWARDS WITH AIR UNTIL CLEAR WHILE WEARING A PROTECTIVE EYE SHIELD. REPEAT AS MANY TIMES AS NECESSARY. DO NOT PERFORM ANY MAINTENANCE OR REPAIRS UNTIL YOU HAVE FOLLOWED THE PRECAUTIONS STATED ABOVE. IF YOU, AS AN EQUIPMENT OPERATOR OR SUPERVISOR, DO NOT FEEL THAT YOU HAVE BEEN ADEQUATELY TRAINED OR INSTRUCTED AND THAT YOU LACK THE TECHNICAL KNOWLEDGE TO OPERATE OR PERFORM MAINTENANCE ON A PIECE OF MAGNUM VENUS PLASTECH EQUIPMENT, PLEASE CALL MAGNUM VENUS PLASTECH BEFORE OPERATING OR PERFORMING MAINTENANCE ON THE EQUIPMENT. IF YOU HAVE ANY QUESTIONS REGARDING THE ABOVE PRECAUTIONS OR ANY SERVICE OR OPERATION PRECEDURES, CALL YOUR MAGNUM VENUS PLASTECH DISTRIBUTOR OR MAGNUM VENUS PLASTECH.

NOTICE: All statements, information and data given herein are believed to be accurate and reliable but are presented without guaranty, warranty or responsibility of any kind express or implied. The user should not assume that all safety measures are indicated or that other measures are not required.

DANGER: Contaminated catalyst may cause Fire or Explosion. Before working on the catalyst pump or catalyst accumulator, wash hands and tools thoroughly. Be sure work area is free of dirt, grease or resin. Clean catalyst system components with clean water only.

DANGER: Eye, skin and respiration hazard. The Catalyst, MEKP, may cause blindness, skin irritation or breathing difficulty. Keep hands away from face. Keep food and drink away from work area.

WARNING: Please refer to your catalyst manufacturer's safety information regarding the safe handling and storage of catalyst. Wear appropriate safety equipment as recommended.

Introduction:

The PPVS is a control valve to provide a positive signal to a Turbo Autosprue (TAS) or IVX3 Injection Valve to Open and Close dependant on the pressure sensed under an infusion film / vacuum membrane. The PPVS-INFUSION fits into the MVP Universal Insert port. It is normally factory set at 800mb absolute.

In operation it provides a positive signal when the mold cavity vacuum injection pressures are below the set point pressure. This signal keeps the IVX3 or TAS open. When the injection pressure reaches the set point the PPVS sends an air signal and consequently closes the IVX3 or TAS thus stopping injection resin flow. This mode of control between opening and closing of the IVX3 or TAS continues until the mold is full.

The pressure set point of the PPVS is always set below atmospheric pressure to ensure the injecting resin never increases in sufficient pressure to force the infusion film away from the fiber pack.

NOTE: It is important to have the correct parts drawing for the item you are working on. This will assist in identifying the correct part numbers for the assembly being rebuilt.

Use Red Grease (6706-2-1 1oz) or Magnum Gun Lube (GL-200 2oz) for the O-rings (3265) on the valve nose.

NOTE: Before starting any service work, release fluid and air pressure from system.

Please read the manual carefully. Follow the steps in the order given, otherwise you may damage the equipment or injure yourself.

During Disassembly . . .
As you disassemble the equipment, lay out the components in the correct order and direction, and have all component drawings available to refer to prior to disassembly.

Overview:

PPVS-INFUSION nose –
(2) 3265 O-rings



Pressure Setting Adjustment –
2.5mm Allen Key

Air Supply / Start – Activates the PPVS - Blue

Output Signal – signal to Close TAS or IVX3



PVS-INFUSION Valve Mode Overview:

OFF Mode – No air supplied to the Start / Air Supply port of the valve. The valve is inactive.

On / Start Mode – by applying an air signal to the Start / Air supply signal port the valve will become active and when the vacuum level reached the set point the valve will send an air signal to do something - Close the IVX3 or TAS.

Active Mode – When the PPVS is On and monitoring the vacuum level and the vacuum level reaches the set point the valve will become active and send an air signal through the Red 4mm tube to do something - Close the IVX3 or TAS

Connections / Positioning:

POSTIONING IN THE MOLD:

***Caution:* Do use an Air supply of more the 6 bar (90psi) or the PPVS will be damaged.**

***Caution*: Too much application of silicon grease *will prevent* the PPVS being pushed far enough into the universal insert to the lock position due to hydraulic effect between the O-ring seals. If it is obvious that the unit will not fully insert remove from insert and clean off excess grease from both the O-ring and PTFE nose section and the mould universal insert before re-insertion.**

***Caution*: This is being placed in a possible resin pressure zone of the production mould which under certain circumstances could result in a PPVS being force up and out of the insert if not locked in.**

Position the PPVS-INFUSION upright at no more then a 45degree angle from vertical and 80mm (3 inches) from the injection point - IVX3 or TAS. It is recommended therefore when arranging the infusion film or building a reusable film that the universal insert for the PPVS and the IVX3 or TAS are situated and laminated in as recommended. Failure to follow this recommendation will simply result in either a too sensitive signal response or too little response signal from the PPVS. In the later case this could lead to over pressurization and pressure inflation of the film.



PPVS-INFUSION Valve with IVx3 Injection Valve

Connections:

PPVS-INFUSION Valve with IVX3– connecting the IVX3 Injection valve to the PPVS-INFUSION will allow for automatic Open / Close control of the IVX3 valve based on the vacuum level. Connect the output signal of the PPVS to the Inject Signal port on the IVX3 valve. Connect the Resin supply Inlet and Outlet as noted above. Connect the Purge Signal port to a purge valve or flush signal. The PPVS-INFUSION should be positioned 80mm from the IVX3 Injection valve or TAS.


Connect the outlet signal of the PPVS-INFUSION to the Injection port of the IVX3 valve
PPVS-INFUSION Valve
Connect the outlet signal of the PPVS-INFUSION to the Injection port of the IVX3 valve
PPVS-INFUSION Valve
Inject
Closed
Purge
IVX3

PPVS-INFUSION Valve with IVx3 Injection Valve in Film Adaptors


Injection Inlet
TAS Injection Valve
Off mold drain valve
Injection signal to PPVS Infusion which controls when injection valve opens
MVP PPVS-Infusion
To Drain
Infusion film under vacuum
Flex Molding infusion universal fittings

PPVS-INFUSION Valve with TAS and Pinch/Drain Valve



Multiple PPVS-INFUSION Valves with Multiple IVx3 Injection Valves and ASSY-0464 3way Resin Manifold

Operating Procedures:

NOTE: Limit air pressure to 6bar (90psi) or the PPVS can be damaged.

NOTE: Apply release agent to the internal 10mm bore of the valve (inside the nose) when the valve is actuated in the inject position (shaft up-most) to prevent the seal sticking up.

Operating Procedures using PPVS and IVX3:

1. Put the IVX3 Valve in the Off mode (CLOSED).
2. Set MPG pressure and pump pressure.

Caution: Do not exceed the Pressure Rating of the injection hose for the MPG or Pump pressure note the ratio of the pump powerhead to fluid section in this calculation.

3. Put the IVX3 Valve in Purge mode (PURGE)
4. Start machine and wait for the resin to start to flow into the supply line, prime valve, resin flows into flush line.
5. Now put the IVX3 Valve in the Off mode (CLOSED). Reset the counter before injecting into the mould for an accurate count.
6. When you are ready to Inject put the IVX3 Valve in Inject mode (Inject position). PPVS should open and close the IVX3 valve automatically and when the valve is closed the machine (Innovator) should stop on the MPG.
7. When the mould is full, put the IVX3 Valve in the Off mode (CLOSED) and stop the machine.
8. Put the IVX3 Valve in Purge mode (PURGE) and then flush. Leave the IVX3 Valve in the Purge mode (PURGE) unit the material is gelled.

NOTE: Leave IVX3 valve in purge mode (with air on the actuator) while the resin cures, this stops resin curing in the valve.

Operating Procedures using PPVS with TAS and Drain Valve:

1. Put the TAS Off / Purge mode and Drain Valve in the Off mode (CLOSED).

2. Set MPG pressure and pump pressure.

Caution: Do not exceed the Pressure Rating of the injection hose for the MPG or Pump pressure note the ratio of the pump powerhead to fluid section in this calculation.

3. Open the Drain Valve (PURGE)

4. Start machine and wait for the resin to start to flow into the supply line, prime valves, resin flows into flush line. Do not Start the PPVS at this time or resin will enter the mould.

5. Now put the Drain Valve in the Off mode (CLOSED). Reset the counter before injecting into the mould for an accurate count.

6. When you are ready to Inject Start (supply) the PPVS (Inject mode). PPVS should open and close the TAS valve automatically and when the valve is closed the machine (Innovator) should stop on the MPG.

7. When the mould is full, turn Off / Stop the PPVS (Off mode) and stop the machine.

8. Put the TAS in Purge mode (PURGE) and then flush. Leave the TAS Valve in the Purge mode (PURGE) unit the material is gelled.

Adjusting the PPVS:

As already mentioned the PPVS is factory set to signal at or very close to 800mb absolute pressure however, if the user should wish to change this setting the following procedure is applied.



Testing and Adjusting using the Calibration Box:

To Test the Vacuum Activation Level:

1) Push the PPVS firmly into the socket at the top of the Calibration Box.

2) Connect the INJECT Output on the control box to the PPVS supply port using 4 mm tube.

3) Connect the 6mm air supply to the Box and turn the air on at supply.

4) Using the Vacuum Level Control adjust the vacuum level Up/Down to determine the vacuum pressure that the valve activates & deactivates at. The indicator will signal red when the valve is active.

Testing PPVS-Infusion for vacuum leak:

1. Load the PPVS valve into the Universal Insert Adaptor port.

2. Connect the INJECT Output on the control box to the PPVS supply port using 4 mm tube.

3. Connect the PPVS signal line to the pneumatic Indicator on the control box.

4. Using the Vacuum Level Control adjust the vacuum to the desired level.

5. Turn the Vacuum Isolator valve to the Closed position (horizontal) to lock the vacuum level – if the vacuum level moves (leaks) down the seal in the valve is not holding vacuum.

To Adjust the Vacuum Activation Level:

1) Insert the 2.5mm Allen Key (6908) into the adjustment screw on top of the valve.

2) Turn the adjustment screw clockwise to lower the vacuum pressure (closer to zero) required to activate the PPVS

3) Adjust the vacuum level to determine the switching point of the PPVS.

4) Repeat this process to achieve the desired switching point of PPVS.

Note: make sure the nut is secure on top of the adjustment screw.

BLIND ADJUSTMENT:

The term “Blind adjustment” means that adjustment can be made without any reference to the actual switching point of the PPVS-Infusion. In other words the user simply turns the adjusting screw anticlockwise by a certain number of turns to make the PPVS more sensitive (higher vacuum level) and clockwise less sensitive (lower vacuum level – closer to zero).

Maintenance:

The only maintenance required for the PPVS is that the front internal PTFE cone body is kept clean and free from any resin build up. It is not normal that resin sticks and builds up inside the PTFE Body. However should this occur and impact upon the PPVS performance then the unit may be disassembled by removing the three body Screws (0313) and Locking Ring (4521).

If the Diaphragm (6642) is removed take care to remove internal Spring (6643) and keep safe. Remove any resin or dirt which might have accumulated in the PTFE body top and reassemble the unit. Do not over tighten Locking Ring.

Once the PPVS is completely re-assembled, test its function. If no test device is available, then connect air supply and the output to the TAS whereupon it is possible to suck* on the PPVS (clean end) to test if it functions correctly.



***Note** Mouth suction vacuum is not normally higher than 500mb absolute*

Specifications:

Supply pressure:	2 - 6 bar - Use 5 micron filtration.
Operating range:	300 -1000 mb absolute max
Connection port:	Stepped 20 and 25 diameters.
Connection lock:	Proprietary spring clip.
Pipe connections:	4mm OD 2.5 ID Recommend flexible polyurethane
Adjustment:	2.5 Allen key.
Contact Materials:	PTFE, cured silicon and Stainless steel.
Weight, dims:	290 grams - 50mm diameter x 86mm H.

Parts Drawings:

22458-2 PPVS-INFUSION ASSEMBLY


SENSITIVITY ADJUSTMENT:
All Units factory set at 800mb absolute.
~ Turn Clockwise to decrease sensitivity.
~ Turn Anti-clockwise to increase sensitivity.
Important Do not overtighten at adjustment limit ends
Use 2.5mm AF Allen Key # 6908
ASSY-0047
6637-Infusion
0668
6887
ASSEMBLY NOTE *:
Note correct orientation of Yoke (#6640).
Thinnest section uppermost.
6640
6522-Blue
air supply
6661
4408
to TAS
6582
6522
7037
6642
6638-Infusion
4521
1260
0313 x 3
6643
6639
3265
PPVS-INFUSION Build Note
Drawing 22458_2
drawn 29/03/10 arh
Issue 1 arh 06/07/10
Issue 2 rw 04/10/2011
MVP Ltd., c 2009 Design rights 2009 , 2010
Install vertical or near vertical
45 Max
Do NOT install

Item Code	Description	Usage Qty
PPVS-Infusion	PPVS Infusion Complete	1.00
6637-Infusion	PPVS Body Top Infusion - Blue	1.00
6642	PPVS Moulded Diaphragm	1.00
6641	PPVS Micro Switch	1.00
6638-Infusion	PPVS Body Lower Infusion -Blue	1.00
4521	Locking Ring	1.00
0313	Socket Cap Head M5 x 20mm	3.00
6639	PPVS Body / Nose	1.00
3265	O Ring Catalyst Pump Red Silic	2.00
6578	O Ring Body Front -Air Ejector	1.00
6643	Spring - Diaphragm PPVS / AC	1.00
6640	PPVS Top Aduster Yoke	1.00
6661	PPVS Yoke Actuator Pin	1.00
1260	Set Screw M4 x 5mm	1.00
6582	Socket Cap Head M3.5 x 20	1.00
6522 - Blue	Tubing PU 4mm Blue	2.00
6908	Hex Key 2.5mm	1.00
7037	PPVS BODY SPACER PLATE	1.00
ASSY-0047	PPVS ADJUSTMENT ASSY	1.00
0298	Washer M4	1.00
6482	Socket Cap Screw M3 x 25mm	1.00
0655-MOD	WORKSHOP MODIFIED PART 0655	1.00
0904-MOD	WORKSHOP MODIFIED PART 0904	1.00
0627	4mm - 1/8 BSP FS	1.00
0636	4mm Tee	1.00
0681	Male Air Connector	1.00

Revision Information:

Rev. 12/2011 Created **PPVS-INFUSION** Valve Manual

Rev. 03/2013 Added the “Terms and Conditions” section. Updated the document format. Added to and updated the Connections section.

MAGNUM VENUS PLASTECH

CORPORATE HEADQUARTERS and MANUFACTURING
11692 56th Court * Clearwater, FL 33760 * Tel 727-573-2955 * Fax 727-571-3636

TECHNOLOGY CENTER and WEST COAST MANUFACTURING
1862 Ives Ave. * Kent, WA 98032 * Tel 253-854-2660 * Fax 253-854-1666

MVP PLASTECH UK
Chilsworthy Beam, Gunnislake, Cornwall, PL18 9AT UK, * Tel:+44 (0) 1822 832621
Fax: +44 (0) 1822 833999

www.mvpind.com